

VIGORPLUS+

Firmware Update Steps

1. Copy all files from the “FW-Update-FW” folder to the root directory of your SD card.
2. Insert the SD card into the main unit and **power it on**. Then connect the **rear camera** to the main unit.
Once the rear camera image becomes stable, **short-press the rightmost button** (as shown below).



3. The preview screen will **freeze**, and the message “Send FW to TX” will appear on the screen.



VIGORPLUS+

4. After about **one minute**, a message saying “Tx Start Update FW” will appear.



5. When the pop-up message disappears, it means the **rear camera firmware update** is complete.

6. The device will then **automatically restart**.